



Process
A0046
1 of 4

Coupling Corporation of America

250 N. Main St. Jacobus, PA 17407 Phone: 717-428-2865 Fax: 717-428-2865 cca@couplingcorp.com

Title **Installation: Standard FLEXXOR**

| Rev | PRCN | By | Appvd | Date |
|------|------|------|-------|-----------|
| Orig | N/A | JTG | JHA | 7/24/97 |
| A | 53 | JTG | JHA | 3/5/98 |
| B | N/A | JHA3 | DDG | 3/25/2015 |

Scope

FLEXXOR shaft couplings are designed to be the most flexible and durable high performance couplings available. Properly installed, they should provide years of maintenance free service. This process is directed toward helping customers understand:

- The fundamental concepts involved in aligning rotating machinery.
- How FLEXXOR couplings are rated.
- How to insure an alignment which does not exceed your coupling's design parameters.
- How to properly install your FLEXXOR coupling.

There are numerous books and papers discussing alignment for those wanting more comprehensive information.

Fundamentals

FLEXXOR shaft couplings have a unique design. Load is transmitted through a series of spoke-like diaphragms. These diaphragms are formed by putting a series of holes in thin and flexible yet very strong material. The adjoining illustration shows how the diaphragms adapt to various types of operating misalignment conditions.

As one would expect, the diaphragms' torque handling ability is greatest when the coupling operates in a neutral (perfectly aligned) condition. Because operating conditions typically cause misalignment, FLEXXORs are designed with a substantial torque handling safety factor. **It is important to align machinery to insure that misalignment limits are never exceeded.** Doing so maintains a sufficient torque handling safety factor.

Proper alignment therefore requires an understanding of operating system requirements (particularly thermal growth), an understanding of the Assembly Drawing and its specifications, and the ability to position the hubs and install the FLEXXOR element as required. Therefore, it is strongly recommended that on-site personnel review operating system requirements with respect to torque ratings, HP, speed, and particularly with respect to thermal growth.

Types of Misalignment




Figure 1



Process
A0046
2 of 4


Coupling Corporation of America

250 N. Main St. Jacobus, PA 17407 Phone: 717-428-2865 Fax: 717-428-2865 cca@couplingcorp.com

Title **Installation: Standard FLEXXOR**

| Rev | PRCN | By | Appvd | Date |
|------|------|------|-------|-----------|
| Orig | N/A | JTG | JHA | 7/24/97 |
| A | 53 | JTG | JHA | 3/5/98 |
| B | N/A | JHA3 | DDG | 3/25/2015 |

Figure 2



25 Mar 2014 Release ID: 51890 Coupling Corporation of America

This proprietary drawing shall not be shared without written permission. Page 1 of 2

| PARTS LIST | | | | | | Design Parameters | |
|------------|---------|---|--|--------|---------|---------------------------------|--|
| Item | Part ID | Description | Material | Qty/Sp | LBM Ea. | 300 lbm | Mass |
| 1 | 002940A | Standard M-400 Diaphragm | Stainless Steel 301 FH | 8 | 1.0 | 6,467 in-lb-in ² | Inertia |
| 2 | 008878- | SLEEVE, 400 | Alloy Steel 4140 | 1 | 48.7 | 212,000 in-lbf | Max. Cont. Torque |
| 3 | 002938C | Sleeve Extension | Alloy Steel 4140 Anl | 2 | 4.7 | 424,800 in-lbf | Peak Torque |
| 4 | 002939E | Hub Ring, Outer Type M-I-SE | Alloy Steel 4140 RC 28-32 | 2 | 21.4 | 6,500 RPM | Max. Speed |
| 5 | 008879- | Clamp Hub Body, 400 | Alloy Steel 4140 RC 28-32 | 1 | 77.3 | 3,370 HP/1000 RPM | Max. Cont. Power/Speed |
| 6 | 008880- | Clamping Collar, 400 | Alloy Steel 4140 RC 40-42 | 1 | 36.8 | 0 HP/1000 RPM | Max. Cont. Power/Speed |
| 7 | 008881- | Clamp Hub Body, 400 | Alloy Steel 4140 RC 28-32 | 1 | 42.5 | 0.300 lb/0.001 in | Axial Spring Rate |
| 8 | 008882- | Clamping Collar, 400 | Alloy Steel 4140 RC 40-42 | 1 | 41.2 | 0.40 deg | Angular Misalignment Per End |
| 9 | 500988 | Cap Screw, Hex Head, 0.625 (5/8)-18 UNF | Grade 9 (min) Coating: Black Oxide | 24 | 0.305 | 1,176 lb-in/deg | Angular Spring Rate Per End |
| 10 | 500156 | Cap Screw, 12 PT Head, 0.625 (5/8)-18 UNF | SAE J429 Grade 8 (min) Coating: Any | 24 | 0.263 | INSTALLATION | |
| 11 | 500460 | Special Screw, Hex Head, 0.3125 (5/16)-24 UNF | NAS 6605 (min) RC 35-40 Coating: Cadmium | 48 | 0.028 | Process Operation | |
| 12 | 500433 | Nut, Hex, 0.3125 (5/16)-24 UNF | MS/MIL 25027 (min) Coating: Cadmium & Dry Film Lubricant | 48 | 0.007 | Parameters | |
| | | | | | | A0052 Install Clamp Hub Driving | Min: 0.000 Max: 0.000 Increment: -0.002 |
| | | | | | | A0052 Install Clamp Hub Driven | Min: 0.000 Max: 0.000 Increment: -0.002 |
| | | | | | | B0154 Balance | BALANCE SPECIFICATION |
| | | | | | | A0048 Alignment | K: 0.014 L: 0.000 M: 0.000 Safe OD: 0.000 Safe Face: 0.000 |
| | | | | | | A0046 Install FLEXXOR | Torque item, XX; to XX ft-lb w/ Loctite 242 |

25 Mar 2014 Release ID: 51890 Coupling Corporation of America

This proprietary drawing shall not be shared without written permission. Page 2 of 2



Coupling Corporation of America

250 N. Main St. Jacobus, PA 17407 Phone: 717-428-2865 Fax: 717-428-2865 cca@couplingcorp.com

Process
A0046
3 of 4

Title **Installation: Standard FLEXXOR**

| <u>Rev</u> | <u>PRCN</u> | <u>By</u> | <u>Appvd</u> | <u>Date</u> |
|------------|-------------|-----------|--------------|-------------|
| Orig | N/A | JTG | JHA | 7/24/97 |
| A | 53 | JTG | JHA | 3/5/98 |
| B | N/A | JHA3 | DDG | 3/25/2015 |

Now inspect the CCA supplied Assembly Drawing for your application (see Figure 2). DESIGN PARAMETERS are found in the upper right hand corner of the second page. NOTE: If the coupling has been designed to accommodate a specified thermal growth, that will be shown as a dimension on the drawing. If there is a discrepancy between the on-site review and the operating conditions shown on drawing, check the COUPLING INFORMATION (or SPECIFICATIONS) to insure a safe application.

If on-site personnel want a pre-stretched or pre-compressed installation to accommodate thermal growth or other shaft movement (such as magnetic centering), and this is not on the drawing, they may add the new dimension to the drawing, but they should not exceed allowable axial travel.

FLEXXOR ratings

While couplings should never exceed their design specifications during the entire operating cycle, it should be noted that installation may require the diaphragms to be compressed more than their **axial travel rating**. Avoid undue force.

Axial Spring Rates are a measure of axial force (both tension and compression) versus the coupling's movement. Actual tests pass the coupling from a neutral state to a compressed state (beyond rated capacity), back to the neutral state, then to state of tension (beyond rated capacity), and finally back to the neutral state. Spring rates are lowest around the neutral state. On occasion, some couplings have a slight negative "spring through." The spring rate specified represents an average across the coupling's range of motion.

Angular Spring Rates similarly measure the coupling's movement relative to angular/offsetting force (see page 1 illustration). Angular Spring Rates likewise vary through the range of motion with the lowest rates near the neutral point. Published values represent an average value.

The **neutral or relaxed coupling length** can be found on the assembly drawing. Because the diaphragms might have a slight bias, physical measurement of the FLEXXOR element could differ slightly. A slight bias may result in the "spring through" action noted above. Use length dimensions shown on drawing.

Couplings are designed to simultaneously meet all stated specifications. **Torque carrying capacity will be reduced beyond design safety factors if misalignment limits are exceeded.** To minimize the impact of operating vagaries, customers should operate this coupling well within specifications.

Aligning Shafts/Hubs

See Process A0048 *Machinery Alignment Guidelines: Shaft Angle and Offset*.

Installing the FLEXXOR coupling spacer



Coupling Corporation of America

250 N. Main St. Jacobus, PA 17407 Phone: 717-428-2865 Fax: 717-428-2865 cca@couplingcorp.com

Process
A0046
4 of 4

Title **Installation: Standard FLEXXOR**

| <u>Rev</u> | <u>PRCN</u> | <u>By</u> | <u>Appvd</u> | <u>Date</u> |
|------------|-------------|-----------|--------------|-------------|
| Orig | N/A | JTG | JHA | 7/24/97 |
| A | 53 | JTG | JHA | 3/5/98 |
| B | N/A | JHA3 | DDG | 3/25/2015 |

1. All surfaces of hubs and coupling - particularly mating surfaces, must be clean and free from burs.
2. Compress coupling element as required. Slide it into position between hubs. Note: there is a slight interference to a line to line fit between coupling and hub. If difficulty is encountered in aligning bolting holes, use push-off holes to hold coupling and hub apart until holes can be aligned.
3. Hand start all fastening bolts on both ends before starting to tighten any of the bolts. Note: Installation bolts have been weight balanced. All bolts of a given Item Number are interchangeable with other bolts of the same Item Number from the same job. **DO NOT MIX BOLTS FROM DIFFERENT JOBS.**
4. You have previously taken great care to properly align hubs. It is extremely important that you take care to carefully torque fasteners to properly "seat" the coupling.

Torquing the bolts

Bolt torque information assumes clean, dry or slightly oiled bolts. Use of other anti seizing compounds will change final torque value. The bolting sequence is repeated several times. All bolts should be tightened to target torque value before going to next sequence. Tighten bolts in an alternating fashion such as: 12:00 - 6:00 - 3:00 - 9:00 - etc.. The sequences are:

1. Tighten **all bolts** to the point where bolt heads **contact flange**.
2. Set torque wrench to **1/2 final torque** value listed on the Installation section of your Assembly Drawing. Tighten all bolts as above.
3. Set torque wrench to **3/4 final torque** value listed on the Installation section of your Assembly Drawing. Tighten all bolts as above.
4. Set torque wrench to **final torque** value listed on the Installation section of your Assembly Drawing. Tighten all bolts as above.
5. **Recheck** all bolts at final torque value.

Removing the FLEXXOR coupling spacer

1. If necessary, secure lifting apparatus to the sleeve.
2. Loosen and remove bolts that connect hub to hub ring.
3. Use the push off holes to release the spigot fits between the hub flanges and the hub rings. Once the diaphragms are compressed, lift the spacer section.

Safety

- Exercise proper housekeeping. Check work site.
- Install coupling guard. Think safety.

Maintenance

While a properly installed FLEXXOR has no maintenance requirements, safe practice recommends visual inspection during machinery shut-down. Check for damage to diaphragms, loose or missing bolts, loose debris or dirt in coupling, or any unusual appearance.

Thank You

Thank you for your business. We trust this FLEXXOR will provide years of satisfactory service. We welcome your feedback.